



NOTE:

- 1. START WITH 1/16" DIAMETER MUSIC WIRE CUT AT LEAST 13-5/16" LONG.
- 2. DO NOT GO OVER DIMENSION "A", OR GO UNDER DIMENSION "B". DOING SO MAY END UP WITH LANDING GEAR THAT WILL NOT FIT IN YOUR TYRO.